

# BACKSCATTER

## TTL FLASH TRIGGER FOR SONY CAMERAS NAUTICAM HOUSINGS

The Backscatter TTL trigger for Sony provides automatic flash exposures with the Backscatter Hybrid Flash. It will also allow High-Speed Sync (HSS) operation with the Hybrid Flash and Mini Flash 2. The Backscatter TTL trigger for Sony is only compatible with the Backscatter Hybrid Flash and will not work with other strobes in TTL operation, but can be used in manual operation with 3rd party strobes.

**Please refer to the Backscatter Hybrid Flash and Backscatter Mini Flash 2 instruction manuals for important information regarding required camera and flash settings for TTL, Manual, and HSS use.**

### INCLUDED ITEMS:

- Backscatter Sony TTL Trigger
- USB-C Charging Cable
- Protective Travel Case
- Protective cap for Sony hot shoe connector

### NAME OF PARTS:

1. On/Off Switch
2. Battery Level Check Button
3. USB-C Charging & LED Light Port
4. Hot Shoe Connector
5. LED Trigger Lights



### HOW TO CHARGE THE BATTERY:

Connect the USB-C cable to the USB-C port. The battery indicator blinks while charging and turns solid when full. It takes 2 hours to charge from empty, but for a quick turnaround between dives, the flash trigger can be charged within a shorter amount of time to a lower battery level that will still provide shooting time.

**NOTE:** High-voltage USB-C cables and high-amp chargers are not compatible with the trigger, please use the included USB-C cable.

### HOW TO CHECK THE BATTERY POWER LEVEL:

Press the battery check button to see the current power level. It will blink from 1 to 5 times to indicate battery level, with 5 times being the maximum battery level and 1 being 20% or less battery remaining.

The trigger can be in active mode for 13 continuous hours of shooting. The trigger will go to standby to save power when the camera goes to sleep or is turned off to save battery power. This way, the trigger can be installed and sealed in the housing the night before and still have plenty of battery power for multiple days of shooting. When opening up the housing to change the camera battery or swap memory cards, it is a good time to check the flash trigger's battery power level.

**CAMERA SETTINGS FOR MANUAL MODE:**

To use the trigger in manual mode with the Hybrid Flash or any other strobe, set the flash to **Wireless Flash** ON in the camera's flash menu.

**CAMERA SETTINGS FOR TTL MODE:**

TTL operation occurs when the **Wireless Flash** is set to OFF. To easily switch between TTL and manual operation, it is recommended to assign one of the custom buttons on the camera to **Wireless Flash** for easy one-button access to switch between TTL and manual.

**INSTALLING THE TRIGGER INTO THE HOUSING:**

The Nauticam Sony Trigger was custom designed to fit directly into Nauticam full frame Sony housings. To install it, simply slide the trigger onto the camera's hotshoe, then load the camera into the housing.

**WATCH THE VIDEO:**

For a detailed walkthrough of how to setup and use the trigger and Hybrid Flash, refer to this instructional video:

[backscatter.com/ttl-flash-triggers](https://backscatter.com/ttl-flash-triggers)

**SPECIFICATIONS :**

Model Number	BS-TR-SN2
Description	Backscatter Flash Trigger For Nauticam Housings
Compatible Camera Models	Sony Cameras (TTL, MANUAL, MANUAL HSS) Other Cameras (Manual Mode only)
Compatible Housing Model	Nauticam Full Frame Housings
Main Material	ABS
Data Transmitters LED Type	High Power Infrared LED
LED Data Transmitters	2-Way LED
Power Consumption	40mW
Battery Power	Built-in Rechargeable Lithium Polymer Battery (3.7V 110mAh)
Battery Charging	By USB Charger DC5V, 0.5A Approx. 2 hours for a full charge
Battery Operation Time	13 Hours (Continuous Operation)
Auto Standby Time	Use With Sony Camera : follows camera's standby state Use With Other Camera : 1 minute
Dimensions	43 x 27 x 21 mm / 1.7 x 1.1 x 0.8 inch
Weight	16.3 g / 0.57 oz
Accessories	EVA Carry Case, USB-C Charging Cable